

RE-PROGRAMMING YOUR REPAIRED

3M XT-1 HEADSET



BASE STATION:

- 1 Press the **MODE** key on base station and enter **1-2-3-4**. Press **MODE** key again. **USER MODE, ID=1** should appear on display screen.
- 2 Press **MODE** three times. The system menu will appear on screen.
- 3 Select **4 - REGISTRATION**.
- 4 Select **add new headset**, then press **enter**.

HEADSET:

- 5 Insert fully charged battery.
- 6 Power on headset and wait for green light to stop blinking.

BASE STATION:

- 7 Wait for display to say "**headset XX has been registered.**"
- 8 Press **MODE** three times, and the system will go back to home screen.

Still having issues? Please call RFT at **(800) 598-2370** for customer support.