Remote Viewing Big Dog Surveillance Cameras from a PC NVMS V3 Quick Setup Guide

Click here to download the installation file -> Download NVMS V3


NOTE: You can also visit <u>https://rfdrivethru.com/surveillance-technical-support/</u> to download application files and related manuals.

Once downloaded, locate the file on your computer and run the executable to begin the installation.

NVMS V3 Installation Wizard:

NVMS V3 Installation W	izard		×
Features to be Installed	Basic Configuration	508 MB	
	🗹 Video	59 MB	
	 Access Control 	27 MB	
	Time and Attendance	13 MB	
	🗹 E-map	13 MB	
	🔽 Data Retrieval and Report	13 MB	
	🗌 AI Dashboard	59 MB	
	V Topology	11 MB	
	Including device&group management	nt, user management, log search, event cente	er, etc
Installation Folder	C:\Program Files (x86)\NVMS V3 Site		
	Required: 644 MB Available: 376987 MB H	HDD Space	


On the first screen, leave the default features checked (see above) and click install. **Note**: If you would like to install to a different directory, you can make that change at this time.



You may be asked to enable upgrade detection. Click Enable.

_ ×
Welcome English \checkmark
 Please create a super user first. A admin
A •••••
Strong
کېرد کېرد
Auto-Login
Login 📐

The next screen will ask you to create a "Super User". It is very important that you remember the username and password you create. If it is lost or forgotten, you will need to uninstall and reinstall the software effectively losing all your presets and configurations. Once you have created your User Name and Password, check the box for "Auto-Login" and click "Login".



The following screen will ask you to create security questions. These can be used to retrieve your password if it's forgotten in the future. **Note**: You will still need to remember your User Name to use this feature and if unsuccessful, your last resort will be to uninstall and reinstall.

Q NVMS V3 ■				🕜 Not Log) 듣 № admin 🕶 A _ 🗆
Video Application				Maintenance and Management
Main View	Remote Playback	Data Retrieval	Report	Device Management Device Management Device Management Terrent Configuration
Access Control				Storage Schedule
			J.NC	ٷ System Configuration
Person	Access Control	Monitoring	Time & Attendance	ন্থ্র System Log Operation Wizard
General Application	_	_	_	Access Control Wizard
2				Time and Attendance Wizard
E-map	Event Center	Security Control P	Topology	×

The next screen will be the main menu page for NVMS software. On the right side under "Maintenance and Management", click "Device Management".

0,1	NVMS V3			🛆 Not Log 🗄 🕢 adm	in \bullet \triangle = \Box ×
88	📰 Maintenance and	Management 💿			
=		Device Stream Media Server	Add		\times
विद्या	Device Management 🔺	+ Add Q Onlin × De 嬲 QR 🖄 Upgra 😅 Refre	Adding Mode:	IP/Domain O IP Segment	O PT Cloud
	Device Management –	Name Connection T Network Param Device Type			 Batch Import
	Device		Add Offline Device		_
	Group		* Name	Reference Name	
			* Address	IP Address or Domain	
	Event Configuration 🛛 👻		Transmission Encryptio		
6	Storage Schedule		* Port	8000	
	Account Management		* User Name	admin	
			* Password	••••••	
रहर	System Configuration		Synchronize Time		_
TO	System Log		Import to Group	×	
				Set the device name as the group name and add all the channels connected to the device to the group.	
				Add and New Add	Cancel
	± ⊡ ⊡ √×				☆ □ ☆

Near the top left of the new window, click the "+ Add" button to bring up the Add Device window on the right. Here is where you will enter your surveillance network specific information. "Name" is for your reference and can be whatever you like. Please work with the Big Dog Support Specialists if you do not know your IP address or Domain information. For all Big Dog Systems the default: Username is: **admin** Password is:

- Before January 2025: bigdog1234
- After January 2025: bigdog@89


Click "Add" when done.

+ Add	Q Onlin	× De 器 QR	≜ Upgra <i>C</i>	Refresh 🖹 Get Event	🕒 Export Total (1)	Filter	
	Name	Connection T Net	twork Param Device Ty	pe Serial No.	Security Level	Resource Us	Firmware Upgrade
	Demo	IP/Domain	Encoding	D	Weak	🕑 Online	i Upgradeable

You should now see your device in the list with the information you just input reflected. If the information was entered correctly, you will see the " **Online**" status.

Alternatively, if you've connected to your DVR/NVR via PT Cloud and LTS connect, you can login to you LTS connect account to access your DVR/NVR by clicking the "Cloud" icon located in the Title bar of the NVMS V3 window. See images below, this will automatically add your video recorder to the list of

devices.		Login
🕜 Not Log 🗄 🕢 admin ▾ 台 _ 臼 ×	Information	User Name/Phone Number
		Password
	? You will enter PT Cloud. Continue?	Login
Total (86) Filter	Yes No	Register



In the top left corner, click the four square icon to return to the main menu.

🧟 NVMS V3			
🔡 🔄 Maintenance	e and Management		
Video Ap	plication		
T			न्म
Main	N	k Data Retrieval	Report
Access Co	h⊰		
	1 III (JUNE

On the main menu, select "Main View" to access the live view of the cameras.

🔠 📑 Main View 🙁 📰 Maintenance and M	anagement
Resource Auto-Switch	
Search Q	
Custom View	
▼ 🛅 Demo 🕞 …	
IP Camera1_Demo	
IP Camera2_Demo	

Click the play button next to your group of cameras to play all cameras in that group. You can also go through the list to view individual cameras. If you would like to view recorded footage, return to the main menu and select "Remote Playback".