



RF APEX PROGRAMMING INSTRUCTIONS

Logging into the Base Station


Press the **SETTINGS**
icon on the Base
Station.



Press the **LOGIN** icon.




Type in password
RF1989 (default) and
then press **LOGIN**.




Register Headset

Turn on a headset
by picking up or
inserting a battery.


After logging in, press
the **HEADSETS** icon.



Press **PAIR NEW HEADSET**.



Pair headsets message, you can now register headset(s).




Register to Base Station

Press and hold the “L1” and “P” switches until the headset starts to beep and the light on the microphone boom flashes green and yellow. Release “L1” and “P.” A long beep will be heard in the headset and the green and yellow light will stop flashing.

Note:

- Can register up to (32) headsets
- Can register multiple headsets at the same time
- If the system is Dual Lane, follow the instructions above, but press and hold “L2” and “P” switches
- When headsets are registered, press exit, then press the **HOME** icon



Still having issues?

For customer support, please call RFT at (800) 598-2370