

Drive-Thru Not Working?

Follow these steps to get your equipment up and running

My System: _____ My Account #: _____

Troubleshooting

STEP 1 | Check Basic Functions of Your Headset

- Change the battery in your headset. Turn it back on.
- Check the base station plug. Reset/unplug the base station for 60 seconds.
- Check the breaker in the breaker box.
- If none of the above steps restore function, follow Step 2.

STEP 2 | Re-Program Your Headset

- Scan the “Re-Program Your Headset” QR code to the right.
- Locate your headset video and follow the steps to re-program your headset.
- If re-programming your headset does not restore function, follow Step 3.



RE-PROGRAM

Still Not Working?

STEP 3 | Call R.F. Technologies, Inc. Phone Support

- Call **800-598-2370** for assistance.
- A technician will assist you in troubleshooting your headset.
- If repairs are needed, please proceed to Step 4 to send in your repair.

STEP 4 | Send In A Repair

- Scan the “Send in a Repair” QR Code to the right.
- Follow the steps on the online form and print your **FREE** shipping label.
- Please securely package your headset, adhere the shipping label and give the box to UPS.
Keep A Record of Your Tracking #



REPAIR

Scan for:
Batteries



Scan for:
**Replacement
Parts**



Scan for:
**Drive-Thru
Parts Finder**



INNOVATIVE, VALUE-DRIVEN SOLUTIONS SINCE 1989

rfdrivethru.com | (800) 598-2370 | sales@rfdrivethru.com

© 2025 R.F. Technologies, Inc. All rights reserved. Strictly confidential and proprietary.